

Vision: to be your reliable supplier from China
Mission: to provide the best Made in China Product and Service
Philosophy: Rooting in China, linking with the world

BH110 INSTALLATION

DESCRIPTION

Breathable BH110 should be installed in accordance with local applicable building code. Weather-resistive barriers should be applied horizontally, with the upper layers overlapping the lower layer by a minimum of 6". It is recommended to tape all vertical seams with RU flashing tape; all seams must be tape to achieve an air barrier install; consult your design professional where necessary.

Rev: March 8,2018 feilereach@126.com www.feilereach.com